

MaschineR Studio

control solution for Reason



Getting Started Guide

version 1.6.4

Table of Contents

1. Installation step by step	6
Step 1: Creating the virtual MIDI ports	6
Step 2: Installing the Remote files	9
Step 2: Loading the "MaschineR" template to your device	11
Step 3: Launching the "MaschineRStudio" application	12
Step 4: Creating Control Surfaces in Reason's Preferences	13
Step 5: Locking Control Surfaces to devices in Reason	14
2. Functional Description	16
General Overview	16
A. Control Modes	17
B. LCD control pages	18
C. Group Selection	20
D. Transport Controls	20
E. Pad Function Selection	21
F. In/Volume Knob	24
G. Edit Buttons	25

H. Jog Wheel	26
2. Kong Controls (Groups A, B, C, and D)	28
A. Knob Control Pages	28
B. Selecting and Editing Drums	29
C. Playing the Drums	29
D. Soloing Drums	29
E. Muting Drums	29
F. 16-Velocity Mode	29
G. Pad Group Assignments	30
3. Dr. OctoRex Controls (Group E and F)	31
A. Knob Control Page	31
B. Playing Single Rex Slices	32
C. Triggering entire Loops	32
4. ReDrum Controls (Group G)	33
A. Knob Control Page	33
B. Selecting and Editing Drums	34
C. Playing the Drums	34
D. Soloing Drums	34

E. Muting Drums	34
F. Step Sequencer Control	35
G. Step Sequencer Pattern Controls	36
5. Master Keyboard Control (Group H)	37
A. Knob Control Page	37
B. Device and Patch Navigation	40
C. Playing a device	41
D. Pad "Notes" Presets	41
E. Step Mode	42
F. Chord Mode	42
G. Solo and Mute	43
6. Mixer Controls (SSL Desk)	44
A. Mixer Mode	44
B. Channel Strip Mode	47
7. Song Navigation Mode	49
8. Settings File	49
Cheat Sheet 1	50
Cheat Sheet 2	51

Appendix A

52

Key Commands Version

52

1. Installation step by step


Step 1: Creating the virtual MIDI ports

Windows:

Windows users will have to install a third party software to create Virtual MIDI Ports. We recommend using LoopMIDI (<http://www.tobias-erichsen.de/software/loopmidi.html>). For video instructions, please refer to this video [HERE](#).

The following text and graphics also explain how to set up LoopMIDI on your computer.


1. Go to the LoopMIDI website, download and install it.
2. Launch the LoopMIDI application. Follow the example below to create the MIDI ports
3. Create 2 MIDI ports: "from MaschineRStudio 1", and "to MaschineRStudio 1"



Mac:

Mac users can use the native IAC bus to create the necessary ports. Please follow these steps. For video instructions, please refer to this video [HERE](#).

Step 1: On your Mac, go to the Applications folders, then open the “Utilities” folder and launch the “Audio MIDI Setup” application. Then from the Window menu, choose “Show MIDI Studio”




Step 2: Double click on the IAC icon to open the set up screen.



Step 3:

- a. keep the device name empty
- b. click on the + sign to create 2 ports and give them the following names "Studio_IN", "Studio_OUT"
- c. click on "Apply"



Step 2: Installing the Remote files

Navigate to the "Remote" folder contained in the "MaschineRStudio" download. Double click on the installer files for your operating system. The installer will create "MaschineRStudio" folders and copy the Remote files to the following directories on your HD:

macOS:

Macintosh HD/Library/Application Support/Propellerhead Software/Remote/Codex/Lua Codex

Macintosh HD/Library/Application Support/Propellerhead Software/Remote/Maps

Attention Mac Users! if you have Reason 11 or later and you did not update from a previous version of Reason but installed from scratch, then the remote files are not installed in "Application Support" but are contained inside the application bundle. Right click on the Reason application icon and choose "Show Package Contents", there you'll find these folders:

Contents/Resources/Remote/DefaultCodex/Lua Codex


Contents/Resources/Remote/DefaultMaps

Windows* (choose to "create directory" when the installer prompts you):


C:/ProgramData/Propellerhead Software/Remote/Codex/Lua Codex

C:/ProgramData/Propellerhead Software/Remote/Maps

* please note, ProgramData is hidden by default on Windows. You need to enable "Show Hidden Files" in the Windows Files Explorer in order to access it.



Installer Mac



Installer Windows


Step 2: Loading the “MaschineR” template to your device

Connect Maschine to the computer. Launch the Controller Editor. Go to “File” and select “Open Template”. Now navigate to the download and go to the “Template” folder. In there you will find “MaschineRStudio.ncmst”. Open it and it will load on your device. This is the template you will be using for MaschineRStudio.




Step 3: Launching the “MaschineRStudio” application

Navigate to the “Max app” folder in the download. Select the folder for your operating system and open it. If you are on a Mac, double click on the file called “MaschineRStudio” (drag this file on the dock for easier launching). If you are on Windows, double click on the file named “MaschineStudioR.exe” (pin it to the desktop for easier launching). After launching the application, it will look like the images below. If you have the Maschine connected, you will see an initialization message on the LCD.




MaschineR app on Mac




MaschineR app on Win with LoopMIDI

Step 4: Creating Control Surfaces in Reason's Preferences

It's time to launch Reason. Go to "Preferences" and select "Control Surfaces". Then click on "Add". In the window that pops up, select "RetouchControl" from the Manufacturer's drop down menu. Then select one of the available control surfaces from the Model menu. There are a total of 10 control surfaces that you need to create. These are "MStudio1Kong", "MStudio2Kong", "MStudio3Kong", "MStudio4Kong", "MStudio5Octo", "MStudio6Octo", "MStudio7Redrum", "MStudioMixer", "MStudioDevices" and "MStudioTransport". Add "MStudioTransport" first and make it the master keyboard. After you add more than one control surface, Reason will issue a warning in the form of a yellow triangle. Simply ignore it as it won't affect anything. This is Reason telling you that more than one control surface are using the same MIDI ports.




Adding control surfaces on Mac
IN port: Studio_IN
OUT port: Studio_OUT




Adding control surfaces on Win with LoopMIDI
IN port: from MaschineRStudio 1
OUT port: to MaschineRStudio 1

Step 5: Locking Control Surfaces to devices in Reason

You can control multiple Reason devices at once in MaschineRStudio if you lock control surfaces to them. Take a look at the file in the "Reason Template" folder. This has 4 Kong devices, 2 Dr.OctoRex's and 1 Redrum. You should consider creating a template file which resembles this one and then lock control surfaces to the devices as shown below. When you re-open the file or create a new one, the "locking" will be remembered by Reason. "MStudioTransport" is the master keyboard and doesn't need to be locked. Also, "MStudioDevices" should be left unlocked so that you can control whichever device has keyboard focus.



Locking "MStudioKong1" to the 1st Kong



Locking "MStudioOcto1" to the 1st Dr.OctoRex

2. Functional Description

General Overview

A. Set the control mode for the LCD area and the Joa Wheel

B. LCDs show information based on the selected control mode. The buttons and encoders control the device in focus. The arrow buttons change control pages

C. Select which Reason device to play

D. Reason transport controls

E. Select the function type for the pads (for example, play, mute, solo etc.)

F. IN buttons allow controls of playhead positions and loop locators, while the OUT buttons allow control of volumes and metering

G. Key commands for edit work





H. Jog wheel: press the arrows to change to a different function.

I. Note Repeat ON/OFF



A. Control Modes

The control mode buttons allow to quickly switch from controlling a rack device to the SSL Mixer or channel strip. They determine what's going to be displayed on the LCD, what is being controlled by the buttons and the knobs, and the function of the jog wheel. In most cases, if you press the button twice, another page of information can be accessed. For more details, please refer to the Device and Mixer control section of this guide.



Control Mode	Function	Submode 1: press once	Submode 2: press twice
	control of Reason rack devices. This mode is selected by default when you select a group	shows the selected device and patch name on the left LCD	(only available in Group H) shows the device parameter names and values of the currently selected bank
	control of the SSL Mixer volume faders, pan pots and widths	shows the Mixer control mode and the name of the selected bank (Volumes, Pans, Widths) on the left LCD	shows the track names and the values of the corresponding control (volume, pan, width)
	control of the SSL channel strip	shows the channel strip control mode and the name of the currently selected strip on the left LCD	shows the channel strip parameter names and the values for the selected bank
	changes the function of the jog wheel	no change	no change

B. LCD control pages

There are a total of 6 control pages which can be used to control different aspects of the application. You navigate to the desired control page by pressing the page select arrows. Unfortunately it is not possible to switch to a specific page remotely, so you need to do this manually. In order to avoid tedious scrolling thru pages, we have tried to keep the page number to a minimum.


Kong pages 1 & 2

Use these pages when controlling devices in Group A, B, C and D



Dr. OctoRex

Use this page when controlling devices in Group E and F




Redrum

Use these pages when controlling a device in Group G




Generic (Devices)

Use this page when controlling any device in Group H, and when controlling the SSL Mixer. This page functions as the “master” and can be used to control any selected device in the rack, including Reason native instruments, effects and Rack Extensions



Chords

Use this page when programming chords for Group H




C. Group Selection

With control surfaces locked to Reason devices as described on page 9, it is possible to quickly switch to control a specific device by pressing one of the group buttons. When a group is activated, the LCD screen will update to show the "name" and the "patch" for the corresponding device. Furthermore, the pads which change color to match the selected group.




D. Transport Controls

Pressing "Duplicate" accesses controls indicated in round "(") parentheses, while pressing "Navigate" accesses controls indicated by square brackets "[]"




E. Pad Function Selection


The "Pad Function" Select buttons change how the pads will behave. The type of functions that these buttons assign to the pads are dependent on the "Group" which is currently selected. Make sure to read the following chapters for more details pertaining to each group.



The following controls are accessed by pressing the "Navigate" button. They can be accessed from any group.




The following controls are accessed by pressing the "Duplicate" button. These can be accessed from any group.




F. In/Volume Knob

The In/Volume knob can be used to change the playhead and locators position. It is also used to meter the master level, change the currently selected device volume (at the device level, not mixer level!), the control room volume and the metromone click level.








G. Edit Buttons


These buttons will trigger keycommands in Reason. They can be useful when editing MIDI notes in the sequencer, especially in conjunction with the jog wheel. For more info on the jog wheel, please consult the next section.



H. Jog Wheel

The jog wheel can be used to accomplish several useful tasks. The first three function pages - Edit, Channel and Browse - control different things, depending on the control mode selected. The table below provides more details. As far as the remaining function pages - Tune, Swing, Volume - these are hard wired and always control the same 3 things, that is Tempo in BPM, Note Repeat Rate and Master Section Volume respectively.



Control Mode	EDIT	CHANNEL	BROWSE
	Submode1: changes the selected device (Group H only) Submode2: changes control bank	Submode1: changes the selected device (Group H only) Submode2: changes control bank	Submode1: changes the patch for the selected device (all groups)
	Submode2: changes the selected channels in banks of 8	Submode2: changes the selected channels in banks of 8	NOT USED
	Submode1: changes the selected channel strip by one Submode2: changes the selected control bank (Dyn, EQ, FXs, etc)	Submode1: changes the selected channel by one	NOT USED
	if "Note" is pressed, it selects consecutive notes in a MIDI clip. if Nudge is pressed, it will nudge the selected MIDI notes forward or back	Zooms horizontally in the sequencer if Nudge is pressed, it will nudge the selected MIDI notes up or down	Zooms vertically in the sequencer
	with group H selected: change the rootnote of the pad layout	with group H selected: change the octave of the pad layout	with group H selected: change the scale of the pad layout



2. Kong Controls (Groups A, B, C, and D)

A. Knob Control Pages

There are two Knob control pages dedicated to Kong. You navigate to them by pressing the page navigate buttons. The controls on each page will update whenever you change groups A thru D to control different instances of Kong.



“Kong” pages

B. Selecting and Editing Drums

In order to select a drum to edit, keep pressed the "Select" button and hit the pad that triggers the drum of interest. The lower right portion of the Left LCD will show the pad that was selected ("P#" where # is the pad number) and the corresponding drum ("D#" where # is the drum number) according to the "Pad Drum Assignment" in Reason.

C. Playing the Drums

Press the "Control" button to use the pads for playing the drums. When "Control" is selected, the pad LEDs will turn on/off in sync with Kong's pads in Reason.

D. Soloing Drums

Press the "Solo" button to turn the pads into "Solo On/Off" switches. When a pad is soloed, the LED will turn on to reflect that change. To clear all "solos", press the "Clear MS" button in the Knob controls page area.

E. Muting Drums

Press the "Mute" button to turn the pads into "Mute On/Off" switches. When a pad is muted, the LED will turn on to reflect that change. To clear all "mutes", press the "Clear MS" button in the Knob controls page area.

F. 16-Velocity Mode

Press the Step button to enter 16-velocity mode. Now the 16 pads will play the selected drum at 16 velocity levels, with pad1 the lowest and pad 16 the highest velocity. You select a drum by pressing "Select" + the pad that triggers the drum of interest.

G.Pad Group Assignments

Pressing the "Pad Mode" button gives access to the "Pad Group" controls to "Link", "Mute" and "Alt" pads as indicated below. You first must select a pad to edit by keeping pressed the "Select" button and hitting the desired pad. When a "Pad Group" assignment is made, the pad LEDs will turn on to reflect the assignment.



"Pad Mode"

3. Dr.OctoRex Controls (Group E and F)

A. Knob Control Page

There is one Knob control page dedicated to Dr.OctoRex. You navigate to it by pressing the page navigate buttons. The controls on the page will update whenever you change from groups E to F or viceversa to control the two different instances of Dr.OctoRex.




“Dr.OctoRex” page

B. Playing Single Rex Slices

With "Control" selected, the pads play the first 16 slices in the loop. With "Step" selected, the pads play the next 16 slices in the loop. To change which loop is currently being triggered by the pads, use the "Note2Sl." knob.

C. Triggering entire Loops

With "Pad Mode" selected, the pads will trigger playback of the entire loop as illustrated below. You need to have "Enable Loop Playback" enabled for this to work. You can enable/disable loop playback directly from the hardware. Loops can be triggered at different quantizations. Use the "Trig Set" button to change quantization to "Bar", "Beat" or "16th note".



"Pad Mode"

4. ReDrum Controls (Group G)

A. Knob Control Page

There is one Knob control page dedicated to ReDrum. You navigate to it by pressing the page navigate arrows.



"ReDrum" page 1

B. Selecting and Editing Drums

In order to select a drum to edit, keep pressed the "Select" button and hit the pad that triggers the drum of interest. The lower right portion of the Left LCD will show the Drum currently selected for editing.

C. Playing the Drums

Press the "Control" button to use the pads for playing the drums. When "Control" is selected, the pad LEDs will turn on/off in sync with ReDrum's drum channels in Reason. Note, only pads 1-10 will trigger sounds as there are only 10 drum channels in ReDrum.

D. Soloing Drums

Press the "Solo" button to turn the pads in "Solo On/Off" switches. When a pad is soloed, the LED will turn on to reflect that change.

E. Muting Drums

Press the "Mute" button to turn the pads in "Mute On/Off" switches. When a pad is muted, the LED will turn on to reflect that change.

F. Step Sequencer Control


Starting with Reason 8.2, it is possible to program the step sequencer remotely from a control surface. To start programming the sequencer in MaschineR, press the "Step" button when in Group G. If the step sequencer is active, you will see a running light advancing from pad 1 to pad 16.

In order to control the step sequencer section, including steps selection, accent and flam, a new page has been added specifically for the step sequencer. You navigate to it just like all other pages, by pressing the left - right arrow keys on the left side of the LCD display.

Programming steps is accomplished by following this procedure:

- 1) select the steps you want to edit with the edit knob; the options are 1-16, 17-32, 33-48, 49-64
- 2) select the drum for which you want to program steps: this is done by pressing "Select" and then hitting one of the pads 1 thru 10, each corresponding to drum channels 1 thru 10 respectively
- 3) select the accent type: this is done with the accent knob. A value of 1 corresponds to "Soft", a value of 2 corresponds to "Medium", and a value of "3" corresponds to "Hard". The default value is "Medium"


If you want to program steps with Flam, turn the "Flam" knob until it displays 1.



"ReDrum" page 2

G.Step Sequencer Pattern Controls

With "Pad Mode" selected, the pads will control which pattern is played by ReDrum's Step Sequencer. You can enable and trigger pattern playback directly from the hardware. In addition, there are key commands for "Randomizing", "Altering", "Shifting Right" or "Left" the patterns. Please note that for these to work, you need to have the ReDrum device selected in the rack. You can do that from the hardware by using the Navigate button and the "Up" and "Down" functions.



Sequencer Control

5. Master Keyboard Control (Group H)

When Group H is selected, the pads will play whichever device has master keyboard focus. Use this group to play the Reason native synths and sampler devices, Rack Extensions, and controlling FX devices. You can also use this group to play Kong, Dr. OctoRex and Redrum. The pad layout will adapt automatically to fit the device currently selected.

A. Knob Control Page

There is a dedicated page for controlling most aspects of the selected device. You navigate to it by pressing the page navigate arrows. In general, you will be able to control whichever device has master keyboard focus in the sequencer from this page. For FX devices, Reason does not create automatically a sequencer track. In order to control an FX device you either need to create a sequencer track for it from the "Edit" menu, or you can lock "MStudioDevices" surface to it. If you proceed with the latter, remember to unlock the control surface from the device once you are done with it if you want to control other devices!

Each device has a number of control banks associated with it. Simple devices might have a few, but complex devices like Thor have up to 24 banks! The name of the currently selected bank is displayed in the lower right side of the left LCD when you are in PlugIn control mode.

To select a different bank, press "Select" and use the jog wheel (in *Edit* or *Channel* function) to scroll thru the available control banks. Once you see the one you want, press on the corresponding bank button. Banks are named according to the section of the device they control. For example, the bank of controls for Oscillator 1 on Thor is labelled "Osc1" and so on.


Each banks consists of 8 controls associated with the 8 LCD encoders. In order to see the name and value of the parameters being controlled by the encoders on the LCD screen, press the "PlugIn" button once more. With the parameter names and values displayed, you can quickly move to other banks again by using the jog wheel (in *Edit* or *Channel* function).

To go back to the main screen, press "PlugIn" again. Pressing "Navigate" + "Step" will open the "Virtual Display" on the computer screen (make sure the MaschineRStudio app is on the foreground for this to work!). This can serve as an additional aid when controlling devices since it displays even more clearly the parameter and bank names.

Group H Main page

Device Type

Selected Control Bank




SELECT

Press "Select" to view the available banks


Use the jog wheel to scroll thru all banks

Press on these buttons to select a different bank of controls





Press the "PlugIN" button twice to view parameter names and values use the jog wheel to change banks



Virtual Display: press "Navigate" + "Step" to open/close it



B. Device and Patch Navigation

You can navigate through devices in the sequencer in two ways:

1. Use the jog wheel in *Edit* or *Channel* function (you have to be in PlugIn submode 1)
2. Press the "Navigate" button and use the "Rewind" or "Forward" buttons in the Transport area to move up or down the track list

When a new device is selected, the LCD will update to display the device and patch names.

To change patches for the selected device:

1. Use the jog wheel in *Browse* function (you have to be in PlugIn submode 1)
2. Press the "Duplicate" button and use the "Rewind" and "Forward" buttons in the Transport


When a new patch is selected, the LCD will update accordingly. Note: you need to be in Group H to see this.

C. Playing a device

Press “Macro” to play the device in master keyboard focus. By default, the pads are configured to send MIDI notes chromatically starting with pad1 sending note C2 and so on. You can shift the pads by semitone or octave and even assign scales as described in the next section.

D. Pad “Notes” Presets

You can change which notes are sent by the pads by pressing “Pad Mode”. Here you will be able to shift the pads up and down by octave or semitone. It is also possible to assign the pads to send notes according to a specific scale. There are 25 scale types to choose from, and these include Major, Minor, the 7 modes, Pentatonic Major and Minor, and a variety of more exotic scales. You can use the pads or the jog wheel to change root note, octave and the scale.



Change the pad layout with the jog wheel




Change the pad layout with the pads

E. Step Mode

When the "Step" button is pressed, the pads function will depend on the device currently selected. They can act as Gate On/Off switches for Thor's Step Sequencer and the RPG-8 device, or as pattern selector for the Matrix or Redrum, or as loop selectors for Dr.OctoRex. In this mode, you'll also be able to access additional slots control banks for the Mimic sampler.

F. Chord Mode

You can program the pads to play "one finger" chords and each pad can have a different chord programmed onto it. Navigate to the "Chord" Knobs control page and press the "Chord On" button. With the top row buttons, you can select a chord type from the ones available. Alternatively, you can program your own chord by using Knob1 for the 1st note in the chord (after the root), Knob2 for the 2nd note in the chord, and Knob3 for the 3rd note in the chord. The chord will be applied to the selected pad only (pad1 is default). To apply the same chord to another pad, press "Select" then hit the pad of interest (the LCD will update to show which pad is currently selected) and then press "Apply 1". To apply the same chord type to all the pads at once, press "Apply 16". To reset the chord for the currently selected pad, press "Reset 1". To reset the chord for all the pads at once, press "Reset All".



"Chord" page

G. Solo and Mute

If you have a Kong or Redrum in master keyboard focus, these buttons will allow you to solo and mute the drums of these two devices. Solo and Mute are otherwise disabled for all other devices.

6. Mixer Controls (SSL Desk)

MaschineRStudio provides extensive controls for the SSL Desk emulation in Reason. You can control not only channel Volumes, Pans, Widths, Mutes and Solos, but you have access to most parameters on the channel strip as well. In order to accomplish this, the controls are divided in two modes of operation:

1. Mixer Mode (Main Mixer controls)
2. Strip Mode (Channel Strip controls)

Please remember, you need to lock "MStudioMixer" to the Master Section in Reason in order to control the SSL desk!

A. Mixer Mode


In Mixer Mode, it is possible to use the encoders to control channel volumes, pans and widths, while the pads can be used as "Mute" or "Solo" switches. To activate "Mixer Mode", navigate to the "Generic" control page using the page navigate buttons, and then press once on the "Mix" button. The LCD will indicate that you are in "Mixer Mode" and it will show which parameters are currently being controlled by the encoders, whether it is volumes, pans or widths. If you are in "Volumes" and want to control "Pans", press "Select" and then press on the corresponding button labelled "Pans" (see below).

When in Mixer Mode, pressing again on the "Mix" button will present a second LCD screen showing the names of the currently active mixer channels along with the corresponding values of the parameters being controlled.

The encoders control the first 8 channels starting from the channel which is set as "Remote Base" (for more information on setting the "Remote Base" channel, consult the Reason manual). To access additional channels, turn the jog wheel in *Edit* or *Channel* mode. One turn clockwise of the jog wheel will move to the next bank of 8 channels. If you prefer to move one channel at a time, keep "Duplicate" pressed while turning the wheel. Please note, changing banks will change which channel is set as "Remote Base" so keep that in mind.

When in "Mixer Mode":


1. Pressing the "Solo" button turns the pads into channel solo switches with pad 1 controlling channel 1 and so on
2. Pressing the "Mute" button turns the pads into channel mute switches. To clear "Mutes" or "Solos", press the "Duplicate" button and then press the "Mute" or "Solo" buttons respectively.




"Mixer" page in Volume mode
Press MIX once




Press Select to change control banks (Volume, Pan, Width)





Press MIX twice to see the channel names and values



B. Channel Strip Mode

To access the channel strip controls, navigate to the "Generic" control page using the page navigate buttons and then press on the "Channel" button to enter "Channel Strip Mode". The LCD will update to display "Channel Strip Mode" and the name of the channel in current "edit" focus.



To give a different channel "edit" focus, turn the jog wheel in *Edit* or *Channel* function. One turn clockwise corresponds to advancing the channel in focus by one. If "Duplicate" is pressed while turning the wheel, you can jump by 8 channels at a time.

Once you have selected the channel strip you intend to edit, press on the "Channel" button once more. This will bring up a second screen where the channel strip parameter names and values are shown and are ready to be edited. Just like it was the case for Reason devices, the parameters are divided in banks of 8 controls each for a total of 8 banks. To quickly switch to a given bank, press "Select" and then press on the button corresponding to the desired bank. You can also switch banks by turning the jog wheel in *Edit* mode.





Press Select to change control banks



Press Channel twice to see the parameter name and values



7. Song Navigation Mode

By pressing the “Scene” button, Song Navigation Mode is engaged. In this mode, the pads can be used to navigate the song in the Reason sequencer. Upon pressing one of the sixteen pads, the left and right loop locators will jump to a respective position in the sequencer and force the playhead to move along as well. The “jump” is quantized to the bar. The length of the jump is determined by the length of the loop. For example, if you have the left locator at bar 1 and the right locator at bar 9, pressing pad 3 will cause the left locator to move to bar 19 and the right locator to bar 27.

You can move both forward and backward in the song, and this is determined by the initial position of the loop locators and the total loop length. Please note, in order for the Song Navigation Mode to work, the distance between the left and right loop locators has to be at least 2 bars.

8. Settings File



The MaschineRStudio application folder contains a “Settings” file which determines the MIDI ports to which the app automatically sets itself upon launching. If you need to change the default MIDI ports to something else, this file can be modified in a text editor but please make sure to save it with the extension “.json” or the app won’t be able to read it.

The “Settings” file can be found in the “support” folder of the MaschineRStudio application folder. If you are on a Mac, right click on the MaschineRStudio icon, then from the context menu select “show package contents” and navigate to the “support” folder.

Cheat Sheet 1

Pad Functions	MACRO	STEP MODE	PAD MODE	SELECT	SOLO	MUTE
Group A, B, C, D (Kong)		16 velocity mode		select drum to edit		
Group E and F (Dr. OctoRex)				not used	not used	not used
Group G (ReDrum)			not used	select drum to edit		
Group H (Master Keyboard)		Gate control for: 1) Thor step seq 2) RPG-8 Pattern control for Matrix		not used	not used	not used

Cheat Sheet 2

	MACRO	STEP MODE	PAD MODE	SELECT	SOLO	MUTE
Mixer Mode	not used	not used	not used	not used	 <p>Ch1-16 Solo Buttons</p>	 <p>Ch1-16 Mute Buttons</p>
Strip Mode	not used	not used	not used	not used	not used	not used



The screenshot shows the PADS menu with the following items:

- 13 SEMITONE -
- 14 SEMITONE +
- 15 OCTAVE -
- 16 OCTAVE +
- SCENE
- Mixer View (Reason 6)
- Sequencer View
- Rack View
- Flip Rack /Tab
- PATTERN
- 9 CLEAR
- 10 CLR AUTOMATION
- 11 COPY
- 12 PASTE
- PAD MODE
- Create Instrument
- Create Effect
- Create Audio (Reason 6)
- Import Audio (Reason 6)
- NAVIGATE
- 5 QUANTIZE
- 6 QUANTIZE 50%
- 7 HUDGE <
- 8 HUDGE >
- DUPLICATE
- Cancel
- Shift
- Up
- Command/Control
- SELECT
- 1 UNDO
- 2 REDO
- 3 COMPARE
- 4 SPLIT
- SOLD
- OK
- Right
- Down
- Left
- MUTE



The screenshot shows the PADS menu with the following items:


- 13 SEMITONE -
- 14 SEMITONE +
- 15 OCTAVE -
- 16 OCTAVE +
- SCENE
- Zoom - Vertical
- Zoom + Vertical
- Zoom - Horizontal
- Zoom + Horizontal
- PATTERN
- 9 CLEAR
- 10 CLR AUTOMATION
- 11 COPY
- 12 PASTE
- PAD MODE
- Delete
- Select All
- Copy
- Paste
- NAVIGATE
- 5 QUANTIZE
- 6 QUANTIZE 50%
- 7 HUDGE <
- 8 HUDGE >
- DUPLICATE
- Quantize
- Right
- Left
- SELECT
- 1 UNDO
- 2 REDO
- 3 COMPARE
- 4 SPLIT
- SOLD
- Undo
- Redo
- P
- MUTE

Appendix A

Key Commands Version

If you are using a version newer than Reason 12, then you need to modify the app settings in order to have compatible key commands. Specifically, you need to modify the "Settings.json" file which can be opened inside any text editor, for example TextEdit on Mac, or NotePad on Windows. The example below shows which line to modify. If you have Reason 13.0.1, just use the major version number, that is 13, and do not include the point version number.

Please make sure NOT to change the file extension and keep it as "json" when saving the file



```
Settings.json
{
  "MaschineIN" : "Maschine Studio Virtual Output",
  "MaschineOUT" : "Maschine Studio Virtual Input",
  "ReasonIN" : " Studio_IN",
  "ReasonOUT" : " Studio_OUT",
  "KeyCmds_Version" : 12
}
```

Change this line with your Reason major version number. Please only use the whole number, no points!

You can find the Settings.json file inside the support files for the MaschineR application:

- on Mac, choose the MaschineR app, then right click on the application icon and choose "Show Package Contents". Then open the "Contents" folder and then open "Resources"
- on Windows, open the MaschineR folder, then "resources" and then "support"